





## **NOTES**

- 1. REMOVE ALL BURRS AND BREAK SHARP EDGES.
- 2. DRILL #30 VENT HOLE IN BOTTOM OF HOOP FOR VENTING OF WELD GASES.
- 3. WELDING OF STEEL LUGS TO BE COMPLETED BY GTAW METHOD TO AMS2685C. WELDING ROD SHALL CONFORM TO ER70S-2 OR EQUIVALENT.









APPROVALS	DATE		
DRAWN: JEFF CLARKE	10 APR 2006		
CHECKED: E. BURGOIN	03 MAY 2006		

UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN INCHES.
TOLERANCES ON:
DECIMALS ANGLES

±1/2°

DECIMALS X.XXX ±0.010 X.XX ±0.03

X.X

±0.1

$\sqrt{\nabla}$	9

## AERO DESIGN LTD.

9888A MALASPINA ROAD
POWELL RIVER, BC, CANADA, V8A 0G3
TEL: 604.483.2376 www.aerodesign.ca

BELL 206L, 407
QUICK RELEASE CARGO BASKET
BASKET COMPONENTS — AFT HOOP

SCALE 1 : 5	DWG. SIZE	DWG. NO.	REV.	
SHEET 2 OF 2	A4	69822	2	